

# SURVIVOR® (ATEX/INMETRO) RIGHT-ANGLE FLASHLIGHT





Custom designed optic with optional, interchangeable Smoke-Cutter® plugs for preferred beam pattern:

- · Black plug signifcantly reduces peripheral light for a tighter beam
- · Amber plug reduces peripheral light and eye fatigue caused by glare

Material/Lens Housing, base and battery housing made from high impact super tough nylon offering exceptional durability. All openings are O-ring sealed for weather resistance. Spring loaded clip with built in D-ring easily attaches to belts and harnesses and reduces unwanted rotation. One way valve for case venting. Available in international safety

### Dims/Weight

Height: 17.92 cm; Height in charger: 22.02 cm; Width: 7.24 cm; Diameter: 7.29 cm; Grip area: Height: 9.14 cm; Thickness: 3.43cm; Width: 5.59 cm Weight: 388g (with lithium rechargeable or AA alkaline); 354g (with AA lithium)

Light Source White LED technology, impervious to shock with a 50,000 hour lifetime

Custom "Total Internal Reflection" optic for narrow beam and optimum peripheral illumination. Insertable black plug reduces peripheral illumination for improved smoke cutting ability or amber plug reduces eye fatigue.

Four lighting modes:

• High for a super-bright beam that pierces through smoke: 41,000 candela; 175 lumens; 405m beam distance; runs 3.5 hours (lithium rech); runs 8 hours (AA alkaline or AA lithium)

- · Low for bright light and longer run time: 14,000 candela; 60 lumens; 237m beam distance; runs 10 hours (lithium rech); runs 20 hours (AA alkaline or AA lithium)
- · Flash for signaling: runs 5 hours
- · Moonlight mode provides low-level lighting for battery conservation: runs 15 days

Switch Rubber dome push-button actuator provides easy operation even when wearing heavy gloves

Battery

Rechargeable smart Lithium 6.2 volt, 1.5 amp hour, 2 cell 18650 can be recharged up to 1,500 times; also accepts 4 "AA" alkaline batteries or 4 "AA" Lithium batteries

Charging

2.5 hour fast charger with full charge indicators or 10 hour steady charger. Both chargers can be used with 100V, 120V, 230V, 240V or 12V DC by exchanging its charge cord. Full charge indication using rechargeable Lithium battery.

- Features Reduced bezel length to minimize snag hazards
  - · Updated clip design for easy attachment on turnout gear
- IP66 rated; dust tight and water-resistant; 2m impact resistance tested
- · Super strong pocket clip

### ATEX/IECEX Approvals

FTZU 15 ATEX 0046X; IEC Ex FTZU 15.0029X II 1G Ex ia op is IIB T3/T4 Ga; II 2G Ex ia op is IIC T3/T4 Gb

DNV 16.0014X Ex ia op is IIB T3/T4 Ga; Ex ia op is T3/T4 Gb (T-Class T4: Streamlight pack 90316, AA type Energizer L91 Lithium, Rayovac 815 or Duracell MN1500. T-Class T3: AA type Energizer E91 Alkaline, Panasonic LR6XP or Panasonic LR6XWA)

Flashlight meets 500°F requirements of NFPA 1971-8.6 (2013). Charger meets requirements of NFPA 1901-14.1.10.2 (2016) mounted in any position. Meets applicable European Community Directives.

## Warranty

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW. You may have other specific legal rights which vary by jurisdiction. Visit streamlight.com for full warranty information

ITEM	UPC	ITEM#
Survivor - 230V AC/12V DC - Orange (ATEX)	080926-90562-7	90562
Survivor - 230V/12V DC - Orange (InMetro)	080926-90580-1	90580
Survivor - 240V AC/12V DC - Orange (ATEX)	080926-90563-4	90563
Survivor - 100V AC/12V DC - Orange (ATEX)	080926-90564-1	90564
Survivor - 12V DC Fast Charge - Orange (ATEX)	080926-90565-8	90565
Survivor - (WITHOUT CHARGER) - Orange (ATEX)	080926-90566-5	90566
Survivor - (WITHOUT CHARGER) - Orange (InMetro)	080926-90581-8	90581
Survivor - Alkaline Model - Orange (InMetro)	080926-90582-5	90582
Survivor - Alkaline Model - Orange (ATEX)	080926-90567-2	90567



Item	UPC	Part #
240V AUS AC Charge Cord	080926-22048-5	22048
DC2 Direct Wire Charge Cord	080926-22050-8	22050
DC1 Charge Cord	080926-22051-5	22051
100V/120V AC Charge Cord	080926-22060-7	22060
230V AC Charge Cord	080926-22061-4	22061
240V AC Charge Cord	080926-22062-1	22062
Steady Charge (SC) Plug-In Charger Holder	080926-90010-3	90010
Fast Charger/Holder	080926-90118-6	90118
DC #1 Fast Charger/Holder	080926-90012-7	90012
DC #2 Fast Charger/Holder	080926-90013-4	90013
Lithium Ion Battery Pack	080926-90316-6	90316
Bank Charger (SC) 120V AC	080926-90400-2	90400
Bank Charger (SC) 230V AC	080926-90600-6	90600
Bank Charger 12V DC	080926-90401-9	90401
Alkaline Battery Carrier (Batteries not included)	080926-90542-9	90542
Survivor (Low Profile) Smoke Cutter Plug Kit	N/A	908019

