

PRODUCT FACT SHEET

SURVIVOR® X ATEX

DESCRIPTION:	ESCRIPTION: The Survivor® X is an intrinsically safe, lightweight, handheld flashlight with a right-angle head designed for use in hazardous locations. This light features a low-profile bezel length to minimize snag hazards. A large translucent button with an LED battery indicator provides gloved access to microprocessor-controlled high and low intensity modes and emergency flash. Optional Smoke Cutter® optic technology offers insertable black or amber plugs for user-customizable beam pattern.		
CASE MATERIAL:	Housing, base and battery housing made from high-impact super tough nylon offering exceptional durability. Spring-loaded clip with built-in D-ring easily attaches to belts and harnesses and reduces unwanted rotation. One-way valve for case venting.		
DIMENSIONS:	Height in charger: 8.67 in. (22.02 cm)	Vidth: 2.85 in. (7.24 cm) Vidth: 2.20 in. (5.59 cm)	Diameter: 2.32in. (5.89 cm) Thickness: 1.35 in. (3.43cm)
WEIGHT:	Li-Ion: 12.2 oz (346 grams) * A	AA Alkaline: 12.8 oz (363 grams) *	
LENS:	Unbreakable polycarbonate with silicone anti-scratch coating assembled in a heavy-duty bezel. O-ring sealed.		
	See chart. Optimized electronics provide regulated intensity. Custom "Total Internal Reflection" optic for narrow beam and optimum peripheral illumination. Optional insertable black plug reduces peripheral illumination for improved smoke cutting ability or amber plug reduces eye fatigue.		
ON/OFF:	Ultrasonic welded push-button switch designed for extremely long life. Translucent rubber dome push-button actuator provides easy operation even when wearing heavy gloves.		
RUN TIME:	See chart. All claims to 10% of initial lumen output. Flash: 8 hrs continuous.		
BATTERY:	2.6Ahr Li-Ion battery pack rechargeable up to 1,000 times available with 120/230/240VAC systems. Fully charges in 5 hours. Charger indicator turns red when charging, turns green when fully charged. Three (3) optional "AA" alkaline or lithium batteries		
BATTERY STATUS INDICATOR:			
FEATURES:	Updated battery door design for improved operation and seal Translucent switch boot with integrated battery status indicator Updated charge cradle for one-handed light removal Multi-fuel design IP67-rated; dust-tight and waterproof to 1 meter for 30 minutes 2-meter impact resistance tested Serialized for positive identification		
APPROVALS**:	$\langle E_x \rangle$ Pending		
** See product for	II 1GD Ex ia op is IIIC T3/T4 Ga/Da T-CLASS T4: Duracell MN1500, Panasonic LR6XJ, Varta 4006, Energizer EN91, Energizer L91 T-CLASS T3: Streamlight pack 90340, Energizer E91, Rayovac No. 815		
specific ratings.			
NFPA Flashlight meets 500°F requirements of NFPA 1971-8.6 (2013). Charger meets requirements of NFPA 1901-14.1.10.2 (2016) mounted in any position. Ce CH Meets applicable European Community Directives.			
OPTIONAL	5-Unit Bank Charger		
ACCESSORIES:	Li-lon Battery	AA Battery	
	FL1 STANDARD HIGH LOW	FL1 STANDARD HIGH LOW	
OUTPUT	250 60 LUMENS LUMENS	250 60 LUMENS LUMENS	
RUNTIME	3h 45min 15h	5h 15h	
DISTANCE	447m 237m	447m 237m	
INTENSITY	Y 50,000cd 14,000cd	50,000cd 14,000cd	

* With battery (based on model; included in purchase) Issued: 06/13/2022 Revised: Rev: 0 All performance claims tested to ANSI/PLATO FL1-2019 Standard