

FOOT PROTECTION AC125 LOW SHOES FOR LADY

PRODUCT DATA SHEET: AC125



PRODUCT CODE:
AC125



FEATURES AND BENEFITS

- The webbing heel loop at the back of the boot enables easy on/off.

APPLICATION

For food industry jobs

PRODUCT DETAILS

Upper:	White microfiber
Tongue:	Brown PU
Collar:	Black PU
Lining – Quarter:	Grey mesh
Lining – Vamp:	White Non-woven
Outsole:	White PU
Midsole:	White PU
Inline sole:	Non-woven
Insocks:	Black anti-bacteria mesh + PU
Padding:	Padded collar with compact flexible foam for extra comfort and better ankle and Achilles tendon protection
Toe caps:	Steel toe cap
Protective midsole:	Steel midsole
Stitching details:	White color
Sole construction:	Injection
Laces:	Elastic band underneath tongue

STANDARDS

CERTIFIED TO:

EN ISO 20345:2022 S3 FO SR

SB	Footwear ergonomics and comfort	SB	Resistance, safety and performance of materials	E	Energy absorption of seat region
WPA	Water resistant upper	P	Antiperforation midsole metallic nail (ø 4,5 mm)	FO	Sole resistance to hydrocarbons
SR	Slip resistance (ceramic floor + glycerine)	SR	Slip resistance (ceramic floor + sodium lauryl sulphate)		
A	Antistatic footwear	S	Toe cap impact 200J +15kN		

WARNINGS AND USE LIMITATIONS

- Do not use in environments exceeding tested conditions (extreme heat, aggressive chemicals, or electrical hazards unless specified).
- Protection may be reduced if the shoes are damaged, improperly fitted, or modified.
- Not suitable for prolonged exposure to strong acids, solvents, or molten materials.
- Replace immediately if any structural damage occurs

CARE INSTRUCTIONS

- Clean with a soft brush or damp cloth after use.
- Use mild soap only; avoid chemicals and soaking.
- Dry naturally, keep away from heat and direct sunlight.
- Do not expose to direct sunlight, fire, or high heat sources (e.g., heaters, dryers), as this may damage the PU sole and upper materials.
- Inspect regularly, replace if damaged.

AVAILABLE IN

PRODUCT CODE	SIZE
AC125	35-48

RELATED PRODUCTS



Head Quarter
Panindochina Building, No 131 Tan Cang Street,
Thanh My Tay Ward, Ho Chi Minh City
Tel: (+84) 28 3512 7509
Fax: (+84) 28 3512 7510
Email: info@panindochina.com.vn

Representative Office In Hanoi
4th, Sannam Building, No. 78, Duy Tan Street,
Cau Giay Ward, Hanoi City
Tel: (+84) 28 3512 7509
Hotline: (+84) 96 815 4868
Email: info@panindochina.com.vn

