

# CGKH4

## Trolley Mounted Breathing Apparatus

Trolley breathing apparatus is especially used in tunnel, pipe or other limited space, and other contaminated environment for a long time difficult and complicated work. Composed of stainless steel trolley, carbon fiber cylinder, air supply tube, reducer, demand valve and full face mask, etc.



### Components:



Full-face Mask



Demand Valve



Gas Cylinder



Cylinder Valve



Harness



Reducer



Tool Box & Air Supply Tube

### Product Specification:

Model	CGKH4-L6.8	Alarm	<ul style="list-style-type: none"> <li>Alarming Pressure: 55±5bars</li> <li>Alarming Volume: 90dB</li> </ul>
Cylinder	<ul style="list-style-type: none"> <li>Quantity: 4</li> <li>Material: Aluminum liner carbon fiber cylinder</li> <li>Volume: 4 x 6.8L</li> <li>Rated Working Pressure: 300bars</li> <li>Rated Service Time: 240mins</li> </ul>	Demand Valve	<ul style="list-style-type: none"> <li>Inhalation Resistance: ≤5 bars</li> <li>Exhalation Resistance: ≤10 bars</li> </ul>
Reducer	<ul style="list-style-type: none"> <li>Input Pressure: ≤ 300bars</li> <li>Output Pressure: About 8.5bars</li> <li>Maximum Output Flow: ≥1000 L/min</li> </ul>	Feeding Hose	(30+10*2)m/(50+20*2)m
Safety Valve	Opening Pressure: 10~15bars	Packing	<ul style="list-style-type: none"> <li>Net weight/gross weight: 63.8kg/81.6kg</li> <li>Dimension: 1.1*0.9*0.72m</li> </ul>

### Recommended Industries/Use

- Chemical
- Construction
- Fire Protection
- Mining
- Oil and Gas
- Steel and Metals
- Manufacturing
- Utilities

### Standards



Contact:

**Xuyen Dong Duong Trading And Services Co., Ltd**

131 Tan Cang Street, Thanh My Tay Ward, Ho Chi Minh City

Tel: (028) 3512.7509 | Fax: (028) 3512.7510

Email: info@panindochina.com.vn | Website: www.panindochina.com.vn